








Endeavor
Mobile Double Sided
Styling Station
Assembly Guide
Sku# 3515ss-M



TOOLS


Philips head screwdriver may be needed
for appliance holder and wheel screws.

COMPONENTS LIST

A		Mirror
B		Cabinet
C		Appliance Holder Ring Inserts x8
D		Crossbar
E		Legs x2

PARTS LIST

F		Wheels x4
G		Bolt/Washer Sets x24




① PRE-ASSEMBLY

Remove and unwrap all pieces from shipping box. Make sure that the box(es) contain
all of the listed parts before beginning assembly.


②

- 1) Attach wheels to legs (E) by screwing into place on each end of the T.
- 2) Line each leg up to the crossbar (D) and insert bolts (4 total - 2 each side) into the bracket welded on legs to secure together.



③


Attach cabinet (B) to legs (E) with two sets of 8 bolt/washers on each side.




④

HOW TO REMOVE DRAWERS

Remove drawers by extending the drawer guides and removing the innermost piece by pushing and holding the tab and sliding the piece out (some tabs need to be pushed \uparrow up and some \downarrow down.)



Remove drawer (see right) to access holes located inside cabinet (B) and use bolts (4 total) to secure mirror (A) to the cabinet.



Assembly complete.

Enjoy your new station!
If you have any questions or problems during assembly please call our customer service at 1.888.332.0123

Thanks for choosing Minerva!

