




# Assembly Instructions

Axis Styling Station

Model #3520




## Parts List

Label	Name	Qty.
A	Station Top	1
B	Mirror	1
C	Leg	2
D	Wall Screws	2
E	Allen Screws	8

### 1 - Attaching the Legs to the Station Top

Lay the Station Top on its side so that the drawers are facing upwards. Be sure to do this on a soft surface to avoid scratches.


Next align the Legs with the holes in the bottom of the Station Top and then screw in the Allen Screws.



### 2 - Attaching the Station Top and Leg assembly to the wall

Before starting the wall mounting process, Remove the drawers from the Station Top. Remove the drawers while the Station Top is still on the floor to avoid putting unnecessary pressure on the legs. To remove the drawers, first pull the drawers all the way out. Then locate the two plastic tabs on either side of the drawers rails. While pushing one down and pulling the other up, pull the drawer out of its hinges.

After the drawers have been removed, locate the wall mounting screws and insert them through the given hole and screw them into the wall.



### 3 - Attaching the Mirror

Find the mirror and hang it appx. 2 inches above the Station Top.

