

MINERVA

Talea Electric Reclining Massage Shampoo System
Model # 5995




PARTS LIST




Chair




Backrest




Basin Support



Basin



4x
Threaded Rods




8x
Nuts & Washer



4x
Lock Washer

Open all boxes to check for parts before beginning assembly.


Tools required (included):




Allen wrench
Wrench (included)

Assembly instructions:


1 Lift the Backrest Cushion (B) upward and pull it away from the Main Chair Frame (A). Using an Allen wrench, remove the two screws located on the back panel of the chair. Then, insert the Allen wrench through the screw holes and gently push to make the holes more visible.




2 Insert the four Threaded Rods (E) into the designated corner holes on the flat mounting side of the Stainless Steel Basin Support (C). Hand-tighten each rod clockwise until firmly seated. Then, thread a Nut (F) onto each rod from the inside of the basin support and tighten until each nut is flush against the interior surface.




3 Carefully lift the Basin Support (C) and align it with the back of the Chair Frame (A).Insert the four Threaded Rods (E) through the corresponding mounting holes in the Chair Frame. From inside the Chair Frame, place one Washer (F) onto each Threaded Rod, followed by one Nut (F). Using a wrench, securely tighten all four nuts to fasten the Basin Support to the Chair Frame.



4 Align the Backrest Cushion (B) with the top of the Chair Frame (A). Slide the Backrest Cushion downward into position until it is fully seated and securely in place.



5 Insert the Shampoo Basin (D) into the holes on top of the Basin Support (C). Slide 1 Lock Washer (G) onto the bolt, followed by 1 Washer (F), and then a Nut (F). Tighten the bolt. Repeat for the 3 remaining bolts.



Test all functions with the chair unoccupied before client use.

WARNING - READ BEFORE USE


This product contains electrical and powered moving components and is installed near a water source. Maximum occupant weight is 350 lbs. Keep electrical components dry and keep hands, feet, clothing, cords, hoses, and objects clear of moving mechanisms. Place the chair upright with the leg rest fully retracted and massage turned off before client entry or exit. Never stand or sit on the leg rest or shampoo basin. Do not allow children to operate or play on or around the unit. Disconnect electrical power before servicing and immediately discontinue use if the chair, controls, plumbing, or electrical system does not operate normally.

If you have any questions or problems during assembly please call our customer service at 1.888332.0123


Thanks for choosing Minerva

HOW TO OPERATE

LEFT-SIDE RECLINE / LEG REST CONTROL




UP / UPPER BUTTON
Press and hold to **extend the leg rest and recline the backrest**. Release the button to stop powered movement.




DOWN / LOWER BUTTON
Press and hold to **retract the leg rest and return the backrest to the upright seated position**. Release the button to stop powered movement.

RIGHT-SIDE MASSAGE CONTROL



UP / UPPER BUTTON
Press to run the **massage clockwise**. Press again to stop the massage.



DOWN / LOWER BUTTON
Press to run the **massage counterclockwise**. Press again to stop the massage.

Before client use: Test all functions with the chair unoccupied. Operate controls only while the client is properly seated. Before entry or exit, return the backrest upright, fully retract the leg rest, turn the massage off, and stop all powered movement.

WARNINGS

PROFESSIONAL INSTALLATION. All plumbing must be installed by a licensed plumber. Before use, a qualified electrician must verify the electrical supply, grounding, required GFCI protection, receptacle location, product rating/certification requirements, and applicable codes. Route the power cord away from water, abrasion, pinching, and moving parts.

MAXIMUM OCCUPANT WEIGHT. Maximum occupant weight is **350 lbs. (159 kg)**. Do not exceed the rated capacity. Only one person should occupy the chair at a time.

POWERED MOVEMENT / PINCH / CRUSH. Keep hands, feet, hair, clothing, cords, hoses, and objects clear of the chair and leg-rest mechanisms. Check the movement path for stools, carts, tools, plumbing lines, electrical cords, personal belongings, and other obstructions. Never reach inside the frame while powered, and never force powered components into position.

CLIENT POSITIONING / ENTRY AND EXIT. Operate powered functions only while the occupant is properly seated. Before a client enters or exits, place the backrest upright, fully retract the leg rest, turn the massage off, stop all movement, and make sure the floor is dry and clear. Do not operate recline or leg-rest functions during entry or exit.

LEG REST / BASIN. Do not stand, sit, kneel, climb, lean, or place excessive weight on the leg rest or shampoo basin. The leg rest is only for the seated occupant's legs and feet; the basin is not designed to support body weight.

CHILDREN. Close supervision is required whenever children are near the unit. Do not allow children to play on, climb on, sit beneath, or operate the chair, controls, leg rest, basin, or moving mechanisms. Disconnect power when unattended if unauthorized operation is possible.

ELECTRIC SHOCK / WATER. Disconnect power before assembly, adjustment, cleaning, or service. Keep plugs, wiring, controls, control boxes, motors, power supplies, and electrical connectors dry. Do not operate controls with wet hands. If water reaches electrical components, disconnect power and do not use the unit until the source is corrected, the unit is dry, and the electrical system has been inspected.

HOT WATER / LEAKS. Verify a safe water temperature before directing water onto a client. Check all supply and drain connections for leaks before electrical power is applied. Disconnect power immediately if a leak develops near electrical components.

DAMAGED OR ABNORMAL OPERATION. Immediately stop use for abnormal noise, vibration, jerking, burning odor, overheating, damaged wiring, loose components, or irregular movement. Do not operate with a damaged cord, plug, control, actuator, motor, wiring, or electrical enclosure. Do not modify the electrical system, controls, frame, massage mechanism, plumbing, or safety components.

STOPPING MOVEMENT. Release the control button to stop powered movement. If movement does not stop when the control is released, immediately disconnect electrical power and discontinue use until the unit has been inspected and repaired.

CLEANING / SERVICE. Use only cleaning products approved for the shampoo bowl and plumbing components. Do not use bleach or Barbicide in the bowl/plumbing; these chemicals may damage seals and contribute to leaks. Disconnect power before servicing.

MASSAGE FUNCTION. Turn the massage off before the client enters or exits. Discontinue use if massage causes discomfort, pain, numbness, dizziness, or other unusual symptoms. The massage feature is intended for comfort and relaxation only and is not intended to diagnose, treat, cure, or prevent any medical condition.

POWER FAILURE. If power is lost while the unit is occupied: stop attempting to operate the controls; keep the occupant seated and calm; do not manually force the backrest, leg rest, or other powered components; and disconnect the unit from the outlet until power is restored. After power returns, reconnect the unit and return the chair to the upright entry/exit position before assisting the occupant out. If operation is not normal, disconnect power and have the unit inspected by a qualified service technician.

EMERGENCY EVACUATION. If immediate evacuation is required during a power failure, assist the occupant out carefully and use additional help if necessary. Do not disassemble or force the powered mechanism while the chair is occupied.