Atikus All Purpose Chair Model #MT-3815				 ALWAYS KEEP HYDRAULIC BASE UPRIGHT. THE HYDRAULIC SHOULD NOT BE STORED OR TURNED UPSIDE-DOWN ! 1) Remove mostly assembled chair from box. 2) Insert headrest into the top of the chair.
PARTS LIST Part Qty. Description				
		L		
A	1	Chair top with base attached		Enjoy your new chair.
В	1	Headrest		Remember to always keep the hydraulic upright. Also be sure not to stand solely on the footrest.
				It is good to pump the hydraulic to full height and back down several times right after assembly to prime the hydraulic fluid. This will keep the pump smooth and responsive. Note that short quick pumping is more effective than pressing the lever all the way down each time.
Open all boxes to check for parts before beginning assembly.				If you have any questions or problems during assembly please call our customer service at 1.888.332.0123 Thanks for choosing Minerva!